



PERSONAL HUMIDIFIER | USER GUIDE

Thank you for purchasing the Crane Personal Humidifier. This humidifier has been manufactured to ensure safety and reliability.

! WARNING: READ AND SAVE THESE INSTRUCTIONS

Failure to follow all of the instructions listed below may result in electric shock, fire and/or serious personal injury.

AVOID:

- Do not allow anyone unfamiliar with this product to use it unattended
- Keep out of reach of small children
- Do not damage the cord or plug or use when the cord or plug is damaged and/or insertion to a power source is loose. *Failure to observe this precaution can result in electric shock, short circuit or fire.*
- Do not use this unit for any purpose other than described in this manual or packaging.
- Do not overload the power source
- Do not use if unit is damaged
- Do not use on unstable surfaces
- Do not leave plugged in when not in use
- Do not place unit upside-down when wet
- **DO NOT USE ESSENTIAL OILS**

ATTENTION:


- Always insert plug securely into the power source
- Regularly clean the plug so dust or sediment doesn't form on it
- Unplug the cord from power source before cleaning
- Do not touch plug with wet hands
- Do not fully immerse the unit or pour water through the mist nozzle.
- Do not use in a wet area such as a bathroom or pool.

Failure to observe or follow these instructions and other warnings can negatively impact the performance of the product, cause it to malfunction or result in electric shock or product damage.


- Do not use anything other than room temperature tap or distilled water
- Keep on/off switch and power port from getting wet
- Change water daily
- Do not insert any foreign objects into the mist nozzle
- Unplug the product before carrying/moving
- Do not place near items that may be damaged by water or mist (i.e. furniture, walls, clothing, etc.)
- Dry the main unit completely before storage
- Store in a cool, dry place
- Do not drop, hit, or otherwise subject this product to excessive shock
- This product has been designed for personal use only. Do not use for industrial use.

INCLUDED: Humidifier, 3 Wick Filters, 120V A/C Adapter, Travel Base, Carry Bag & Manual

VOLTAGE:
5V DC



PARTS:



USAGE INSTRUCTIONS:

1. **LET THE WICK FILTER SOAK 5-10 MINUTES BEFORE USE**
2. Pour water into the Travel Base provided (or any standard cup) until water reaches at least the minimum fill point. *TIP: Product consumes approximately 1 ounce of water per hour.*
3. Place humidifier in the base.
 - **Avoid** getting the on/off button or plug wet
 - **Do not** fully immerse in water
4. Plug into a power source using the USB or A/C plug. Indicator light will illuminate red.
5. Press the power button. Indicator light will illuminate blue and mist will emit from the nozzle.
6. After use, press the power button again to turn power off.
7. The humidifier will automatically stop producing mist when the water level gets too low. The indicator light will turn red. Add more water to the base and press the power button to continue operation.

AFTER POWER ON, it may take several minutes before mist appears. This is normal and not a malfunction. It is recommended to use a sturdy, stable base to prevent tipping during use.

CARE & WEEKLY MAINTENANCE:

ALWAYS unplug from power source before cleaning.

Do not immerse or pour water onto the on/off switch or power port of the unit.

- Wipe with a water-dampened cloth
- Take out wick filter by twisting above & below indicator light to separate the top & bottom. Rinse with water.
- Remove wick & dry all parts before storing.
- Use vinegar and water mixture to clean the top & underneath the mist nozzle where the wick is placed.

WARRANTY:

This product is warranted to be free from manufacturing defects under normal use and conditions for **1 year**. This warranty **requires a copy of your dated proof of purchase.**

WARRANTY IS VOID IF THE DEFECT IS DUE TO: Accidental damage, misuse, abuse or neglect, use of essential oils, improper repair or alteration by unauthorized persons, or failure to follow operating instructions provided.